






Add pet feeder via Bluetooth



Scan code to get the "WOpet Life" App



STEP 1







Search the app store or scan the QR code to download and install the app called **WOpet Life**.

STEP 2

Open the app, click "Log In".
Tips: If you haven't an account, please click "Sign Up" to create an account.

STEP 3

Please choose the correct country or the Area, enter an email and the password, read and agree to the privacy policy, then click Next.



STEP 4


Click "+ Set Up Device" or plus button at the top right corner to add a new pet feeder.

STEP 5

Click Turn on Bluetooth and click Turn on now.

STEP 6

Click Pair



STEP 7



Choose Wi-Fi and enter password, then click Next.

STEP 8

Click the Done button at the bottom to complete the connection.



If the feeder is failed to connect, please add the feeder using the Wi-Fi mode



STEP 1



Click "+ Set Up Device" or plus button at the top right corner to add a new pet feeder.

STEP 2

Find the Heritage View 10 pet feeder under the Add Device Manully.

STEP 3

Select Wi-Fi connection mode in the upper right corner, press and hold the Setting button for 5 seconds, wait for the green light to flash, and click to go to the next step.



STEP 4

Select 2.4 GHz or 5 GHz Wi-Fi network and enter password, then click Next.

STEP 5

Go to the Wi-Fi settings on your mobile phone and connect to the Wi-Fi which starts with SL-WOpet--xxx.

STEP 6

Return to the app after the Wi-Fi is connected.

STEP 7

Click the Done button at the bottom to complete the connection.

FAQs

1. Troubleshooting method of connection failure:

- 1) Check whether the pet feeder is plugged in (The power adapter must be plugged in to successfully connect to Wi-Fi)
- 2) Check if the wifi strength is strong enough and reset the router. The distance between the feeder and the router should not be too far, within 10m is recommended..
- 3) Check the indicator lights'station is consisten with the app descriptions. If not, changing them by long-pressing the Setting button.
- 4) Switch Wi-Fi mode to try again.
- 5) Re-download the app and reset the pet feeder.

2. The device does not dispense food as scheduled?

- 1) The feeder is using 24-hour military time system.
- 2) When there is food blocking, the feeder won't dispense food, clean the food residual in the food outlet, and clean the inside of food bucket.
- 3) Check if the wifi strength is strong enough and reset the router. The distance between the feeder and the router should not be too far, within 10m is recommended.
- 4) Please try to manual feeding to check if the motor is turning properly.
- 5) Please reset the feeding schedule to have a try.

3. What if I receive a food blackage message in my feeding log?

- 1) Check if food is clogged in the dispensing tunnel.
- 2) Manually clear out food from the tunnel in the food bucket, and check if food is stuck at turnplate.

4. How do I hide the camera on my device?

- 1) Click the camera logo in the bottom left corner of the camera page to hide the camera.

If the connection fails, please provide the information to contact our after-sales team, we'll get back to you within 24 hours. (support@wopet.com)

- 1) Your order number.
- 2) The virtual ID of feeder.
- 3) The video failed to connect.